V4f



CysBOX

CysBOX User Manual





SUMMARY

1	SPECI	FICATIONS	
2	Using t	he Autopilot	5
	2.1 Cys	sBOX – User Interface (UI)	5
	2.1.1	CysBOX – Starting AutoPilot Control	5
	2.1.2	CysBOX – AutoPilot Control	6
	2.2 Cys	sBOX – Calibration dialog	9
	2.2.1	Alignment	9
	2.2.2	Rudder	
	2.2.3	Settings	
	2.3 Cys	sBOX – Configuration dialog	
	2.4 Cyl	Pilot-Dashboard	
	2.5 Lea	arning Manager	
	2.6 Cys	sBOX - Interface Web (WebUI)	
	2.6.1	CysBOX - Control	17
	2.6.2	CysBOX - Gain	
	2.6.3	CysBOX - Calibration	
	2.6.4	CysBOX - Configuration	
	2.7 RC	- Remote Control	
3	CYPIL	OT SOFTWARE INSTALLATION	
	3.1 Inst	tall the cypilot package	
	3.1.1	Install package	
	3.1.2	Complete installation	
	3.1.3	Customize configuration to match your boat specifications.	
	3.2 Set	tings files	24
	3.2.1	cypilot_deviation.conf	24
	3.2.2	cypilot_sensors.conf	24
	3.2.3	cypilot_serial.conf	
	3.2.4	cypilot_dprint.conf	27
	3.2.5	cypilot_calypso.conf	27
4	CONFI	GURATION - SETTINGS	
	4.1 IML	J Device	
	4.2 Cal	lypso Ultrasonic Wired BLE	
	4.3 Rer	mote Control	32
	4.4 GP	S	33
5	INSTA	LLATION	
	5.1 Cor	nnections CysBOX	
	5.1.1	Power	35
	5.1.2	Audio	35
	5.1.3	NMEA1 – NMEA2	35
	5.1.4	COM1 – COM2	
	5.1.5	CAN	
	5.1.6	USB	
	5.1.7	PC	
	5.1.8	HDMI - Network	
	5.2 Cor	nnections CysPWR	38
	5.2.1	Power	38
	5.2.2	Motor	38
	5.2.3	Rudder	39
	5.2.4	Clutch	39
	5.2.5	COM	40
	5.2.6	CAN	40
	5.3 Exa	ample : GD testing equipment	41



CysBOX

1 SPECIFICATIONS



CysBOX is an open and scalable system which allows the electronic management of the boat by using the most recent technologies (ARM processors, radio communications, etc.) while remaining compatible with existing wiring (NMEA183, NMEA2000, etc.).

The main application of the CysBOX system is the CyPilot software. CyPilot is an innovative and scalable autopilot that allows different operating modes, from simple PID mode to more advanced modes (auto tuning, etc.). It allows the development of new operating modes based on self-learning algorithms.

CysBOX is an open system that allows the use of most browser software: qtVlm, OpenCPN, Signal K server, etc.



The CysBOX hardware is made up of following modules:

- **CysBOX**: central unit, "heart" of the system, which offers advanced functionalities based on open-source software: existing software (signal-K server, mapping, etc.) or own developments (pilot, alarm management, etc.)
 - Processor:
 - Quad-core ARM at 1.5GHz (Raspberry Pi4B)
 - Connectivity:
 - USB: 3 x USB "Host"
 - PC: 1 x USB "Device"
 - *NMEA1, NMEA2*: 2 x NMEA0183
 - COM1, COM2: 2 x HS serial links (1 Driver, 1 GP)
 - **CAN**: 1 x NMEA2000
 - AUDIO: 1 x Analog/Audio
 - HDMI: 1 x Video (optional external screen)
 - GPS: 1 x SMA (active GPS antenna)
 - *RF*: 1 x SMA (RF remote control antenna)
 - LAN: 1 RJ45 Gigabit/Ethernet
 - Internal functions:
 - Slot Pi4B:
 - I/O 40 and USB3
 - Power management
 - Gigabit/Ethernet and Wi-Fi
 - Bluetooth
 - HUB USB (1 reversible port for PC connection)
 - GPS: update rate up to 18Hz (U-Blox)
 - 9-axis IMU: 10Hz measurement frequency (BNO085-Hillcrestlabs)
 - RF433Mhz: CysRC pilot remote control (RFM69)
 - UART HS:
 - NMEA2000 (CAN gateway ATMEGA64M1)
 - NMEA0183 (2)
 - HS serial port (2 including CysPWR pilot link)
 - 433MHz radio interface (dedicated to the CysRC pilot remote control)
 - Analog / Audio interface
 - Applications:
 - Pilot (CyPilot)
 - Voice alarms (CyAlarm)
 - Open source applications compatible with Raspberry OS
- CysPWR: power unit for helm control
 - Processor:
 - ATMEGA64M1
 - \circ Connectivity:
 - *Power*: 1 x DC04 Power input (max 40A)
 - Motor: 1 x DC04 Helm motor output (eg: L&S clutch, max 40A)
 - Rudder: 1 x AU05 Rudder angle sensor and temperature probe inputs (option)
 - *Clutch*: 1 x AU05 Cylinder clutch output and Bar stop inputs (*option*)
 - Serial: 1 x AU05 Serial link HS CysBOX
 - CAN: 1 x NMEA2000 (option)
- **CysRC**: remote control (IP68)



eys

2 Using the Autopilot

2.1 CysBOX – User Interface (UI)

2.1.1 CysBOX – Starting AutoPilot Control

The User Interface is launched by double-clicking UI Icon

This starts the autopilot and activates the remote control.

When Autopilot is active, an icon **v** appears in the system taskbar.



A click on this icon stops the autopilot, and displays or hides the execution log:





2.1.2 CysBOX – AutoPilot Control



This is the main control dialogue of the autopilot

V4f



- (1) ON/OFF button \rightarrow the color indicates the mode:
 - Green: ON
 - Orange: OFF

2 Algorithm Pilot:

- Simple: basic PID algorithm
- Auto-tune: automatic selection of the best PID values depending on wind speed, angle, ...
- Learning: auto-learning algorithm based on recorded navigation data
- ③ Current Heading / wind angle / rudder angle
- 4 Autopilot setpoint (heading, wind angle, rudder angle)
- (5) Autopilot Mode:
 - Compass: use compass heading
 - GPS: use GPS heading
 - Wind: use apparent wind angle
 - TrueWind: use True Wind angle
 - Rudder: use rudder angle

6 Autopilot algorithm settings:

- P
- D
- |
- H – G
- 0
- M

⑦ 10° Port

- 8 1° Port
- (9) 1° Starboard
- 10° Starboard

Tack command by a long press on («) (»).

Note :

The "simple" and "autotune" modes are based on a PID control algorithm.

PID stands for Proportional, Integral, Derivative:

P: Proportional action: linear reaction proportional to the error

I: Integral action: intervenes to correct the static error

D: Derivative action: intervenes during rapid changes

The additional parameters H, G, O, M make it possible to refine the behavior of the autopilot.

H: Heel: coefficient to correct the heel

G: Gain: coefficient to correct the amplitude of the helm command according to the speed of the boat

O: Overlay: adds additional processing (PID)

M: Calculation time of average wind conditions in Autotune mode

CysBOX



Display in "learning" autopilot mode					
CyPilot Control 🗸 🗸 🗙					
simple LEARNING autotune					
	Heading		Command		
	-21 ° -1 °				
compass	gps	wind	true wir	d RUDDER ANGLE	
MLPRegressor_h	eading_model	MLPRegressor_cm	ng_model MLP	PRegressor_predict_model	
~~	<	0/1	>	>>	
	Displ	ay in "autotune" a CyPilot Contr	utopilot mode	~ ^ X	
simpl	e	learning		AUTOTUNE	
	Heading -22 °		Com-	nmand 1 °	
compass	gps	wind	true wind	RUDDER ANGLE	
P			G		
2.83	0.24 0	.27 0.13	5.9	-3.0 29.0	
	<u> </u>	0/1	×	22	

A long press on the "AUTOTUNE" button activates the selection dialog parameters depending on the wind conditions.

Operation in "autotune" mode is the same as in "simple" mode but the P/I/D/H parameters are automatically selected according to the navigation conditions.

The file: "autotune_settings.txt" in the configuration directory: /home/pi/cypilot-settings allows to define the sets of parameters for different conditions of wind mode and wind speed





2.2 CysBOX – Calibration dialog

The In the main menu, open the file **CyPilot tools**-**Calibration client** to launch the calibration procedures: alignment of the inertial unit (IMU), rudder control settings (Rudder), and settings (Settings)

2.2.1 Alignment



- 1 Resetting the alignment settings of the boat,
- 2 Current heading
- 3 Angle on the pitch axis in degrees
- 4 Angle on the roll axis in degrees
- (5) Angle on the heel axis in degrees
- (6) Initialization of boat alignment settings (IMU) based on the current position of the boat

Progress of the alignment procedure

- \bigcirc Visualization of the boat according to:
 - sea
 - boat
- 8 Setting the heading correction



CysBOX

Alignment procedure

The autopilot _____ must be stopped (Disengaged).

- Click on the "Boat is level" button when the boat is stable in navigation position. The progress bar allows you to follow the alignment procedure. The calibration values "Pitch" "Roll" "Heel" must be close to 0 and the model of the boat aligned.
- 2. Adjust the exact "Heading" by setting the "Offset" field → the compass heading of the boat must be equal to that of the "Heading".

<u>Note:</u> a declination and deviation table allow precise correction according to the magnetic heading. (Settings directory: **/home/pi/.cypilot**, File: **cypilot_deviation.conf**)



2.2.2 Rudder

- 1 Rudder angle
- 2 Max angle of the port/starboard rudder
- ③ Resetting rudder stops

		CyP	ilot Calibratio	on	× ^
IMU	Rudder	Settings			
		or Position		2 Puddor Papao	
		23.77 °		+/- 48.0 °	
Calibra	ation proc	edure:			
Step1	: reset cu	rrent calibration		Reset calibra	tion
Step2 : enter rudder range		48°	1 × 1		
Step3 : put full helm to turn starboard		Starboard			
Step4	: put full I	nelm to turn port		Port	
Step5	: put the i	rudder in the cen	ter position	Center	
Press	the butto	ns to move the h	elm to turn s	starboard or port:	
1		<<		>>	

Rudder angle sensor calibration procedure

The autopilot

must be stopped (Disengaged).

- 1. Click on the "Reset calibration" button \rightarrow Step2 and Step3 are now accessible
- 2. Follow Step2 to 5

0/1

Note: provide a margin of safety before mechanical stops

<u>Note:</u> If the control servomotor cannot be mechanically disengaged, e.g. in the case of an external actuator, it is possible to position the bar with the buttons («) (»). The bar movements are of low amplitude as long as the calibration procedure is not complete, to avoid stress on the mechanical stops. When the calibration is complete, the "Starboard" "Port" "Rudder centered" buttons and the "range" field are grayed out and the "Offset" "Scale" and "non-linearity" values are displayed.



2.2.3 Settings

	CyPilot Calibration	× ^
IMU Rudder Settings		
ap.tack.angle	100,00deg	\$
ap.tack.delay	3,00sec	•
ap.tack.rate	10,00deg/s	•
servo.brake	5,00%	•
servo.max_current	12,00amps	•
servo.period	0,27sec	•
servo.speed.max	100,00%	÷
servo.speed.min	80,00%	•
sow.coefficient	100,00%	•
wind.coefficient	100,00%	÷
wind.offset	0,00deg	\$

This dialog allows you to choose the main parameters:

ap.tack.angle	Tack angle	degree
ap.tack.delay	Delay before tacking	seconds
ap.tack.rate	Tacking rate	degree/second
servo.brake	End of bar movement braking	%
servo.max_current	Max servomotor current	amperes
servo.period	Rudder control period	seconds
servo.speed.max	Max servomotor speed	%
sow.coefficient	Surface speed	%
wind.coefficient	Wind patch	%
servo.speed.min	Min servomotor speed	%
wind.offset	Wing angle offset	degrees



2.3 CysBOX – Configuration dialog

	CyF ilot Client	• •
alues Filters		
servo.version_firmware	201	•
servo.voltage	12.38	-
servo.voltage.factor	0.99	O
servo.voltage.offset	0.48	
servo.watts	0.0	-
signalk.period	0.5	0
signalk.uid	cypilot-65458978008	-
sow.coefficient	100.0	
sow.source	none	-
sow.speed	False	-
timestamp	58828.99	-
wind.angle	False	-
wind.coefficient	100.0	O
wind.direction	False	-
wind.offset	0.0	
wind.source	none	-
wind.speed	False	-

The main parameters are accessible through the calibration dialog. The **Client** dialog allows the reading of all <u>parameters.</u>

V4f



CysBOX

The "Filters" tab allows you to choose the values saved on the autopilot server that are displayed: - depending on the type of value:

- Settings: configuration parameters Sensor Values: sensor values (wind, gps..) -
- etc.... _
- depending on the name

	CyPilot Client		~ ^ X		
Values Filters					
Select type of parameters t	o be displayed (settings, properties,):				
✓ Settings					
✓ Properties					
✓ Values					
 Sensor Values 					
✓ Timestamp					
Enter text to select paramet	ter names to be displayed:				
Frampler					
- 'pilot' to display any prop	erty which name contains 'pilot'				
- empty line or '*' to displa	y all the parameters				
		CyPilot Clier	nt		~ ^ X
	Values Filters				
			4		
	ap.pilot.learning.model MLPRegresso	pr_predict_model	MLPRegressor_h	eading_model	•
	ap.pilot.learning.period	1.0	0		
	ap.pilot.learning.version	v1	-		



2.4 CyPilot-Dashboard

CyPilot Dashboard is launched by double clicking on the icon

CYS
Dashboard

Real-time data display							
	CyPilot Dashboard						
POLAR SPD	TWS	SOG	SOW				
4.3 kt	10.3 kt	5.7 kt	5.7 kt				
AWA	AWS	TWA	DRIFT DIR				
20.0 °	15.5 kt	31.0 °	79.0 °				

To choose the parameters displayed: left or right click in each data panel and scroll.



CysBOX

2.5 Learning Manager

In order to exploit the "learning" mode of the autopilot, it is necessary to create a "learning model" file from the recorded navigation data "learning data".

The program for creating the **"learning model"** is launched by the shortcut "Learning **Manager**" installed on the desktop in the **"CyPilot Tools"** directory:

learninggui.py 🗸 🗙 🗙					
Welcome to autopilot model creator wizard. WARNING: if there is already a file named learning_model.pkl in the save directory, he will be overridden.					
Extraction directory:					
/home/pi/logfiles/learning_data	Browse				
Save directory:					
/home/pi/.cypilot	Browse				
R	un				
New model registered: Models caracteristics: Decision Tree Heading Model MeanAE : 0.43088599018003265 MedianAE : 0.1920000000000017 MeanSqrE : 0.5571640561702127 MaxE : 7.156999999999965 Linear Regression Heading Model MeanAE : 0.8979607128809562 MedianAE : 0.6614479655395828 MeanSqrE : 1.4919511740299385 MaxE : 7.897275176729739 Decision Tree CMG Model MeanAE : 0.16680890768782902 MedianAE : 0.15135177310525802 MaxE : 11.492064391743014 Linear Regression CMG Model MeanAE : 0.8699792861200932 MedianAE : 0.15742448318295914 MeanSqrE : 2.1368038538925465					
0	%				



2.6 CysBOX - Interface Web (WebUI)

The Web User interface is launched by double-clicking the WebUI icon

This launches the autopilot and activates the remote control.

WebUI

2.6.1 CysBOX - Control



(1) ON/OFF button \rightarrow the color indicates the mode:

- White: OFF
- Green: ON
- 2 Heading / wind angle / rudder angle
- ③ AutoPilot setpoint (heading, wind angle, rudder angle)
- ④ 1° Port
- (5) 10° Port
- 6 1° Starboard
- ⑦ 10° Starboard
- 8 Reminder of the operating mode: Compass, GPS, Wind, True Wind, Rudder
- 9 AutoPilot Server Status
- 10 Servomotor status
- (11) Server response time
- (12) Errors and servomotor link information

V4f



2.6.2 CysBOX - Gain

					~ ^ X
	Control	Gain	Calibration	Configuration	Statistics
	Mode compass Pilot simple ~	• 1) 2			
	P	-			=1.92
	ı —	-			0.214
3) D				0.085
	н ——				0.1
	G 😐				-0
	0				-10
	Mode: compass				
2	Server: connecte	d			

1 Operating mode: Compass, GPS, Wind, True Wind, Rudder

- 2 Pilot algorithm: simple, auto learning
- 3 Algorithm parameters
 - Ρ _
 - _ T
 - _ D
 - H G O



2.6.3 CysBOX - Calibration

	cypilot cor	ntrol	~ ^ X
Control Gain	Calibration	Configuration	Statistics
(1) (2)	(3) (4)		
Magnetic Heading 40.069 Pitch	-0.509 Roll 0 Heel 0		
5 Devices the best is to	and an other also to stated a		
Press nere) when the boat is le	evel to align the inertial s	sensors. (6)	
Magnetic Heading Offset 0		Degrees	
	$\overline{\mathcal{O}}$		
8			
Rudder -9.75	(11)	10	
Offset 133 69 Scale 402 88 Non	Linearity 151 Rudder F	CIZ)	
12	Elleanty 151 Rudder F		
- calibrate - < starboard - <	port - centered -		
Budder Dange 40	Dograaa		
Ruduel Range 40	Degrees		
(14)			
Mode: rudder angle			
Server: connected			
Servo: SYNC			
Errors:			
Litoro.			

- ① Current heading
- 2 Angle on the pitch axis in degrees
- (3) Angle on the roll axis in degrees
- 4 Angle on the gite axis in degrees
- (5) Initializing Boat Alignment Settings (IMU) depending on the current position of the boat
- 6 Alignment progress
- \bigcirc Setting the heading correction
- 8 Rudder angle
- 9 10 11 12 Rudder angle sensor calibration value
- (13) Resetting rudder stops
- (14) Max angle of the port/starboard rudder



CysBOX

Alignment procedure

The autopilot **AP** must be stopped (Disengaged).

- Click on the Press "Here" button when the boat is stable in navigation position The progress bar allows you to follow the alignment procedure. The calibration values "Pitch" "Roll" "Heel" must be close to 0.
- 2. Adjust the exact "Heading" by setting the "Magnetic Heading Offset" field → the compass heading of the boat must be equal to that of the "Magnetic Heading"

Rudder angle sensor calibration procedure

The autopilot AP must be stopped (Disengaged).

- 1. Click on the "Calibrate" button → the "Starboard" "Port" "Centered" buttons and the "Rudder Range" field are now accessible.
- 2. Set the maximum bar travel in the "Rudder Range" field
- **3.** Manually set the bar successively in each of the positions "Starboard" "Port" "Centered" and click on the corresponding button when the bar is in the desired position.

Note: provide a margin of safety before mechanical stops.

<u>Note:</u> If the control servomotor cannot be mechanically disengaged, e.g. in the case of an external actuator, it is possible to position the rudder with the buttons (-) (+). The rudder movements are of low amplitude as long as the calibration procedure is not complete, to avoid stress on the mechanical stops. When the calibration is complete, the "Starboard" "Port" "Centered" buttons and the "Rudder Range" field are grayed out and the "Offset" "Scale" and "Non-Linearity" values are displayed.



2.6.4 CysBOX - Configuration

		cypilot cont	rol		~ ^ X
Control	Gain	Calibration	Configu	ration	Statistics
Display: Clea	ur ○ Dark ○				
ap.tack.angle	;		113.8	deg	
ap.tack.delay	1	•	⊃ 0	sec	
ap.tack.rate		-	10	deg/s	
servo.max_c	urrent		15.59	amps	
servo.period		-	0.4	sec	
servo.speed.	max	-	• 100	%	
servo.speed.	min		80	%	
wind.offset			0	deg	
	•				
Mode: rudder	angle				
Server: conne	cted				
Servo: SYNC					
Latency: 6.2 m	S				
Errors:					

This dialog allows you to choose the main parameters:

ap.tack.angle	Tack angle	degree
ap.tack.delay	Delay before tacking	seconds
ap.tack.rate	Tacking rate	degree/second
servo.max_current	Max servomotor current	amperes
servo.period	Rudder control period	seconds
servo.speed.max	Max servomotor speed	%
servo.speed.min	Min servomotor speed	%
wind.offset	Wing angle offset	degrees



2.7 RC - Remote Control

- 1 1° port
- 2 1° starboard
- ③ ON/OFF
- 4 10° port
- (5) 10° starboard



- Pairing with the CysBOX \rightarrow press +10° and -10° at the same time
- Change mode (wind/compass) \rightarrow press +1° and -1° at the same time
- Tack to starboard \rightarrow +1° and ON/OFF at the same time
- Tack to port \rightarrow -1° and ON/OFF at the same time



3 CYPILOT SOFTWARE INSTALLATION

Current CysBOX software has been tested under Raspberry Pi OS bullseye (Debian version 11) which must be installed on CysBOX Raspberry Pi4B

3.1 Install the cypilot package

3.1.1 Install package

While pip alone is sufficient to install from pre-built binary archives, up to date copies of the setuptools and wheel projects are useful to ensure you can also install from source archives: sudo python3 -m pip install --upgrade pip setuptools wheel

Install cypilot from wheel file: sudo pip3 install cypilot-1.0.0-cp39-cp39-linux_aarch64.whl or, to install from pypi the latest officially published release: sudo pip3 install cypilot

note: to uninstall = sudo pip3 uninstall cypilot==1.0.0

3.1.2 Complete installation

After package has been installed, installation must be completed using the **cypilot_init** command: **cypilot_init**

At least, select -1- from main menu, then step -1,2,3- from the opened submenu, and -4- to reboot.

3.1.3 Customize configuration to match your boat specifications.

Update the configuration files which are located in \$HOME/.cypilot directory:

- NMEA, COM, ... ports assignment
- sensor priorities
- ...

Calibrate IMU (mounting position, gyro, heading, ...) using cypilot_calibration utility.



3.2 Settings files

The /home/pi/.cypilot directory contains the software's data and configuration files. Parameterization files allow to adapt the system to the configuration of the boat.

3.2.1 cypilot_deviation.conf

Compass deviation to apply to magnetic headings:

```
{
"0": 0,
"90": 10,
"180": 20,
"270": 10,
"360": 0
}
```

The deviation value is added to the value indicated by the magnetometer to calculate the true heading. For example, with the values above, the magnetic heading 090 indicated by the magnetometer is corrected by +10°.

CysBOX

Note: the correction applied is not really the "deviation", but rather the sum of "deviation+declination"

3.2.2 cypilot_sensors.conf

Priority of the different sources for the sensors:

```
{
    "priority": {
        "gpsd": 4,
        "servo": 1,
        "ble": 1,
        "serial": 2,
        "tcp": 3,
        "signalk": 4,
        "none": 5
    }
}
```

If a value is published by different sources, only the source with the highest priority will be retained (1 = highest priority).

For example, with the default values above, if the apparent wind speed is supplied both by the BLE anemometer and by the serial link NMEA bus, the value supplied by the BLE anemometer will be retained.

V4f



3.2.3 cypilot_serial.conf

The **cypilot_serial.conf** file is used to define the operating parameters for each serial port. For example, for the **/dev/ttysNMEA1** port associated with the **NMEA1** connector:

```
{
    "path": "/dev/ttysNMEA1",
    "baudrate": 4800,
    "protocol": "nmea",
    "input_filter": [],
    "output_msgs": [],
    "description": "NKE Display Output"
}
```

For each serial port, the following parameters can be defined:

- "**path**": device path
- "baudrate": baudrate
- "protocol": nmea, gps, servo
- "input_filter": list of NMEA messages to filter
- "output_msgs": list of NMEA messages to send
- "description": free text

The "path" parameter selects the serial port:

- external connections:
 - /dev/ttysNMEA1 (CysBOX-V3 alias /dev/ttyUSB0): NMEA1 connector (NMEA0183)
 - /dev/ttysNMEA2 (CysBOX-V3 alias /dev/ttyUSB1): NMEA2 connector (NMEA0183)
 - /dev/ttysCOM1 (CysBOX-V3 alias /dev/ttysUSB2): COM1 connector (RS232)
 - /dev/ttysCOM2 (CysBOX-V3 alias /dev/ttyUSB3): COM2 connector (RS232)
 - built-in peripherals:
 - /dev/ttypCAN (CysBOX-V3 alias /dev/ttyAMA0) = CAN/NMEA2000 gateway
 - /dev/ttyuGPS (CysBOX-V3 alias /dev/ttyACM0) = uBlox GPS

The "protocol" parameter selects the use of the port and the associated communication protocol:

- "nmea": NMEA0183 connections or CAN/NMEA2000 gateway
 - "gps": GPS connection
 - "servo": CysPWR power unit connection

The "**input_filter**" and "**output_msgs**" parameters define the behavior of the system for the reception and transmission of NMEA messages on the communication ports:

NMEA message reception from external equipment:

TCP port:

Cybele Services

- the message is decoded and the sensor values are updated
- the message is forwarded to all active TCP connections
- COM/NMEA serial port:
 - if the message type is in the "input_filter" list :
 - the message is ignored
 - if the message type **is not** in the "**input_filter**" list :
 - the message is decoded and the sensor values are updated
 - the message is forwarded to all active TCP connections
- transmission of an NMEA message from the internal sensors (XDR,HDM,RMC,GLL,MWV,RSA) :
 TCP port:
 - the message is encoded and transmitted to all active TCP connections
 - COM/NMEA serial port:
 - the message is transmitted on the serial link if the message type is in the "output_msgs" list

V4f



cypilot_serial.conf file, default values for CysBOX-V3:

```
[
  {
     "path": "/dev/ttysNMEA1",
     "baudrate": 4800,
     "protocol": "nmea",
     "input_filter": [],
     "output_msgs": [],
     "description": "NKE Display Output"
  },
  {
     "path": "/dev/ttysNMEA2",
     "baudrate": 38400,
     "protocol": "nmea",
     "input_filter": [],
     "output_msgs": [],
     "description": "Vesper AIS Input"
  },
  {
     "path": "/dev/ttyCOM1",
     "baudrate": 38400,
     "protocol": "servo",
     "input_filter": [],
     "output_msgs": [],
     "description": "CysPWR Rudder Servo Input/Output"
  },
  {
     "path": "/dev/ttyCOM2",
     "baudrate": 4800,
     "protocol": "nmea",
     "input_filter": [],
     "output_msgs": [
       "RMC",
"GLL"
    ],
"description": "NKE TopLine Input/VHF ASN GPS Output"
  },
  {
     "path": "/dev/ttypCAN",
     "baudrate": 115200,
     "protocol": "nmea",
     "input_filter": [],
     "output_msgs": [],
     "description": "CysBOX NMEA2000 GW Input/output"
  },
  {
     "path": "/dev/ttyuGPS",
     "baudrate": 115200,
     "protocol": "gps",
     "input_filter": [],
     "output_msgs": [],
     "description": "CysBOX U-Blox GPS Input/Output"
  }
]
```





CysBOX

3.2.4 cypilot_dprint.conf

When the Autopilot program is launched separately by the Autopilot shortcut or by the Autopilot system menu, an execution log is displayed in a window.

Each line begins with the name of the module that publishes the information: pilot_imu, nmea, gpsd, autotune, ... It is possible to filter this information by the name of the module:

```
- allowed: list of authorized modules ("any" = all)
```

- excluded: list of filtered modules ("none" = none)

```
{
    "allowed": [
        "any"
    ],
    "excluded": [
        "none"
    ]
}
```

Example:

- to display only the tracks from the "autotune" and "gpsd" modules:

```
"allowed": [
      "autotune", "gpsd"
   ],
   "excluded": [
      "none"
   ]
}
    - to display all traces except those from the "signalk" module:
ł
   "allowed": [
      "any"
   ],
   "excluded": [
      "signalk"
   1
}
```

3.2.5 cypilot_calypso.conf

Calypso BLE Anemometer MAC Address and Reading Period:

{"mac_address":"fd:3d:c3:20:16:a9","poll_period":0.01}



4 CONFIGURATION - SETTINGS

4.1 IMU Device

For IMU calibration (BNO085), set the autopilot to Stop

Click

Type cypilot_bno085 in the window:

>_

	×
Fichier Édition Onglets Aide	
pi@CysBOX-4:~\$	-
	Ļ

Define how the CysBOX will be mounted in the boat,

type m

and carefully follow the instructions displayed by selecting the different mounting axes of the box



For example for an assembly of the vertical **CysBOX** to starboard: choose **d s w**



CysBOX

Enter BNO X physical axis alignment (n/e/s/w/u/d) or q to quit BNO X Axis is aligned Down Enter BNO Y physical axis alignment (n/e/s/w/u/d) or q to quit BNO Y Axis is aligned South Enter BNO Z physical axis alignment (n/e/s/w/u/d) or q to quit BNO Z Axis is aligned West Hit <space> to continue and save mapping data, q to quit Physical orientation set : ('d', 's', 'w') Please run calibration procedure now

Perform the calibration procedure with the c command

If you need to test or calibrate the IMU, use following command: s : start reading IMU data e : start reading IMU (Euler Angle only) m : map device physical axis c : calibrate q : quit Execute factory calibration - Follow instructions Clearing current calibration ... Step 1 : Position the device in a relatively clean magnetic environment Begin observing the Status bit of the Magnetic Field output Rotate the device in a figure 8 until calibration quality is high (hit <space> to continue, q to quit) Magnetometer Calibration quality: High Accuracy, (3) Step 2 : Perform the accelerometer calibration calibrate the accelerometer by positioning the device in 4-6 unique orientations Ensure the device is stable for ~1s in each orientation (hit <space> to continue, q to quit) Step 3 : Perform the gyroscope calibration Set the device down on a stationary surface for ~2-3 seconds to calibrate the gy roscope (hit <space> to continue, q to quit) Step 4 : Perform the magnetometer calibration motions Rotate the device ~180° and back to the beginning position in each axis (roll, p itch, yaw) Rotation speed should be about 2 seconds per axis (hit <space> to continue and save calibration data, q to quit)

Run the e command to read the data from the IMU

If you need to test or calibrate the IMU, use following command: s : start reading IMU data e : start reading IMU (Euler Angle only) m : map device physical axis c : calibrate q : quit Start reading IMU data - Press any key to stop FusionPose (deg): 3.120, 0.697, 35.240

Roll, pitch, heading data are in degrees

V4f



Launch

C

CysBOX: Calibration Alignment

Check on the model and adjust, if necessary, the offset on the heading



4.2 Calypso Ultrasonic Wired BLE

For pairing the anemometer with the CysBOX, set the autopilot to Off



Type **cypilot_ble** in the window:

pi@CysB0X-4: ~	
Fichier Édition Onglets Aide pi@cysB0X-4:~\$	
pi@CysBOX-4:~ ~ * *	
<pre>pi@CysB0X-4:-\$ cypilot_ble ble_calypso > Version: 0.3.6 ble_calypso > If you need to pair a Calypso BLE anemometer, use following command: a : enter Calypso Anemometer MAC Address c : print current configuration file w : start wind measurement s : stop wind measurement q : quit</pre>	Enter a
pi@CysBOX-4: ~ ∨ ∧ ×	
Fichier Édition Onglets Aide	
<pre>ble_calypso > Version: 0.3.6 ble_calypso > If you need to pair a Calypso BLE anemometer, use following command: a : enter Calypso Anemometer MAC Address c : print current configuration file w : start wind measurement s : stop wind measurement q : quit</pre>	Fill in the MAC Address of the Calypso
<pre>ble_calypso > uwble failed to initialize BLE device : Failed to connect to peri pheral c8:3a:cf:52:22:aa, addr type: random ble_calypso > Enter the MAC Address of the Calypso wind sensor (example: c8:3a: cf:52:22:aa) MAC Address: c8:3a:cf:52:22:aa</pre>	
pi@CysBOX-4: ~ ✓ ✓ ▲ ★	
Fichier Édition Onglets Aide	
pi@cysb0x-4:-S cypilot_ble ble_calypso > Version: 0.3.6 ble_calypso > If you need to pair a Calypso BLE anemometer, use following command: a : enter Calypso Anemometer MAC Address c : print current configuration file w : start wind measurement s : stop wind measurement q : quit	The anemometer is paired with the CysBOX
<pre>ble_calypso > uwble failed to initialize BLE device : Failed to connect to peri pheral c8:3a:cf:52:22:aa, addr type: random</pre>	
<pre>blo_calupse_ > Enter the MAC_Address of the Calupse wind sensor (avample: c8:2a) cf:52:22:aa) MAC Address: c8:3a:cf:52:22:aa ble_calupse > uwble config has been written: {"mac_address":"c8:3a:cf:52:22:aa ","poll_period":0.01}</pre>	



Taper y

4.3 <u>Remote Control</u>

For pairing the remote control with the CysBOX, set the autopilot to Off



Type **cypilot_rc** in the window:



Then start pairing following the procedure:

Press the 2 down arrows simultaneously Then release





Fichier Éc	ition Onglets Aide			
pi@CysBOX-4 receiver If you need use follow: y : enter n : return d : debug r : RSSI n q : quit	<pre>:-\$ cypilot_rc > Version: 0.3.6 > Use CysBoxRC key to contr to appair a new device, ng command: in appair mode to transmit mode easure</pre>	rol.		
receiver receiver receiver receiver receiver	> Appair mode > 20 > Someone ask for key > Sending appair key > Returned to transmit mode	3		

The remote control is paired.

4.4 <u>GPS</u>

The setting of the GPS receiver can be done with a PC connected via USB to **CysBOX.** However, the measurement frequency is always updated by the autopilot when it is initialized.

Prerequisite:

- PC windows10 with U-Blox U-Center software (<u>https://www.u-blox.com/</u>)
- USB cable type USB B male to USB A male

Install U-Blox software Connect the PC to the **CysBOX** PC connector Launch the U-Center software

The port used appears in Windows Device Manager as: "Serial Port USB (COMXX)"

📇 Gestionnaire de périphériques	-	×
Fichier Action Afficha ?		
🗢 🔿 🖬 📝 🗊 💭		
> 🏣 Périphériques système		^
🔉 🏺 Périphériques Universal Serial Bus		
🗸 🛱 Ports (COM et LPT)		
Périphérique série USB (COM26)		
USB Serial Port (COM23)		
💭 USB Serial Port (COM24)		- 64
USB Serial Port (COM25)		
🛱 USB Serial Port (COM27)		
USB Serial Port (COM28)		~



5 INSTALLATION

5.1 Connections CysBOX





5.1.1 Power

The **CysBOX** module is supplied with 12V via a 4-conductor cable:



- 1 GND (Black)
- 2 +12V (Red) to connect on permanent 12V power supply via a 2A fuse
- 3 GND (Green)
- 4 POWER (White) to be connected to the On/Off control switch on the board

The **CysBOX** module is permanently powered, the On/off status is controlled by the POWER wire and a two-tone LED is used to control the status of the system:

- Off: Powered down
- Startup: blue then high intensity orange during startup, then low intensity blue in operation
- Shutdown: blue then high intensity orange during shutdown, then low intensity blue before extinguishing

5.1.2 Audio



The PWM0 and PWM1 outputs allow the broadcast of Audio messages. This possibility is exploited by the CyAlarm monitoring software for the emission of alarms by voice messages.

5.1.3 NMEA1 – NMEA2



The NMEA1 and NMEA2 connectors allow the connection of NMEA0183 devices. Related devices: /dev/ttyUSB0 and /dev/ttyUSB1



5.1.4 COM1 - COM2



The COM1 and COM2 connectors allow the connection of equipment via serial links: isolation \pm 50V, EIA/TIA-232 and V.28/V.24 standards with high speed up to 250kbps.

One of these connections is used for connecting the **CysPWR** power module to the **CysBOX** module. Related devices: /dev/ttyUSB2 and /dev/ttyUSB3

5.1.5 CAN



The CAN connector allows the connection of NMEA2000 type equipment.

Interconnection is provided by an Atmel ATMEGA64M1 processor that can be programmed to provide NMEA2000 gateway functionality.

By default, it is programmed in NMEA2000/NMEA0183 mode with management of PGN Heading, Variation, Speed, Depth, Position, Wind to a 115200bps serial connection. It can be reprogrammed using the Arduino environment via the standard bootloader, or Atmel Solution via the programming connector hard the board. Associated device: /dev/ttyUSB4

5.1.6 USB



Three **USB Host** connectors allow the connection of external USB 2.0 devices: keyboard, mouse, or external USB sensors.

An external Bluetooth V4.0 interface allows a better range for Bluetooth V4.0 devices than the interface integrated into the CysBOX module and may be required to use for example the Calypso Ultrasonic anemometer.



CysBOX



If a PC is connected to the **USB Device** connector, all the peripherals and sensors in the **CysBOX** module can be directly controlled by the PC instead of the local processor.

It is thus possible to use a PC to reprogram the **CysPWR** rudder control processor, the CAN/NMEA2000 interface processor, to set up the GPS module, to test the connectivity of all the sensors, or to use the **CysBOX** module as a simple PC peripheral set.

5.1.8 HDMI - Network

The HDMI and Network RJ45 connectors are managed by the PI4 processor internal to the **CysBOX** module: they allow the use of an external display and connection to a wired network.



5.2 Connections CysPWR



5.2.1 Power

Power input connected to the battery:



Max current: 40A

5.2.2 Motor

Rudder control power output:



Adjustable max current 0-40A (PWM output)



5.2.3 Rudder

Rudder angle sensor:



Example: NKE rudder angle sensor wiring uses pins 1, 2, and 3

5.2.4 Clutch

Rudder servomotor clutch:



- 1 : GND
- 2: Clutch : control (active : 0V)
- 3 : Clutch : power supply (output 12V 2A)
- 4 : port mechanical stop detection (option)
- 5 : starboard mechanical stop detection (option)

Note:

- the Clutch output can be configured for use of pins 2 and 3 in common control outputs active at 0V. In this case the max current reaches 4A and an external 12V connection must be connected directly to the clutch solenoid.

V4f



5.2.5 COM

Serial link: interconnection with the **CysBOX** module Isolation ±50V, standard EIA/TIA-232 et V.28/V.24 with transmission rate up to 250kbps.



5.2.6 CAN

Connector CAN/NMEA2000 (option)





V4f

5.3 Example : GD testing equipment

